

2018 Exchange pool items

PART NUMBER	DESCRIPTION	PLATFORM							
9696	MOTOR				AS350			EC130	
41830	INDICATOR ROTOR RPM				AS350			EC130	
55670	LIGHT GRADUATOR				AS350	AS355		EC130	
402504	MOTOR WINDSHIELD WIPER				AS350	AS355		EC130	
060-00015-0000	DIRECTIONAL GYRO		DHC8		AS350	AS355	EC120		EC135
060-0015-00	DIRECTIONAL GYRO	DHC6	DHC8		AS350	AS355	EC120		EC135
066-03038-0000	R.M.I.				AS350	AS355			EC135
066-03046-0005	PICTORIAL NAVIGATION INDICATOR				AS350	AS355			EC135
066-03051-0000	ALTIMETER				AS350				EC135
066-03063-0000	ADF INDICATOR				AS350	AS355			EC135
066-3038-00	R.M.I.				AS350	AS355			EC135
066-3046-05	PICTORIAL NAVIGATION INDICATOR				AS350	AS355			EC135
066-3051-00	ALTIMETER				AS350				EC135
066-3063-00	ADF INDICATOR				AS350	AS355			EC135
071-01052-0000	FLUX VALVE				AS350	AS355	EC120		EC135
071-01053-0004	SLAVING ACCESSORY				AS350	AS355			EC135
071-01242-0001	SLAVING ACCESSORY				AS350	AS355	EC120		EC135
071-1052-00	FLUX VALVE				AS350	AS355	EC120		EC135
071-1053-04	SLAVING ACCESSORY				AS350	AS355			EC135
071-1242-01	SLAVING ACCESSORY				AS350	AS355	EC120		EC135
1-1223-03	FUEL GAUGE INDICATOR				AS350			EC130	EC135
150SG114Q	STARTER GENERATOR				AS350			EC130	
150SG117Q	GENERATOR STARTER				AS350				
150SG122Q (350A54-0201-809)	STARTER GENERATOR				AS350			EC130	
160SG140Q1	STARTER GENERATOR				AS350		EC120		
1U56900	INDICATOR QUAD				AS350			EC130	
200DC	DIRECTIONAL GYRO	DHC6			AS350			EC130	EC135
200SGL130Q	GENERATOR STARTER				AS350			EC130	
205-1BL	DIRECTIONAL GYRO				AS350	AS355		EC130	

2018 Exchange pool items

23032-020	GENERATOR STARTER			AS350	AS355	EC130	
23032-042	STARTER GENERATOR			AS350		EC130	
2306-556-00-10 / -20	INDICATOR FUEL QUANTITY			AS350		EC130	
2309-355-00-10 / -11	AMMETER			AS350		EC130	
2309-355-00-20	AMMETER			AS350		EC130	
3057-3-136/-1/-5/-6	INDICATOR TORQUE			AS350		EC130	
3057-3-136-1	TORQUE INDICATOR			AS350	AS355	EC130	EC135
3057-3-136-5	TORQUE INDICATOR			AS350	AS355	EC130	EC135
3057-3-136-6	TORQUE INDICATOR			AS350	AS355		EC135
3057-3-136A	TORQUE INDICATOR			AS350			EC135
3057-3-137	TORQUEMETER INDICATOR			AS350			EC135
3057-3-137 (704A47-621-087)	INDICATOR TORQUE			AS350		EC130	
31026-010	SERVO, MAIN ROTOR			AS350	AS355	EC130	
31026-110	SERVO, MAIN ROTOR			AS350	AS355	EC130	
350A31-0033-XX	ABSORBER VIBRATION			AS350			
350A32-0010-XX(X)	GEARBOX MAIN ASSEMBLY INCL OIL PUMP & ROTOR BRAKE & EPICYCLIC			AS350			
350A32-0011-XX(X)	GEARBOX MAIN ASSEMBLY INCL OIL PUMP & ROTOR BRAKE & EPICYCLIC			AS350			
350A32-0012-00P	GEARBOX MAIN ASSEMBLY INCL OIL PUMP & ROTOR BRAKE & EPICYCLIC			AS350			
350A32-0012-XX(XX)	GEARBOX MAIN ASSEMBLY INCL OIL PUMP & ROTOR BRAKE & EPICYCLIC			AS350			
350A32-0013-XX(X)	GEARBOX MAIN ASSEMBLY INCL OIL PUMP & ROTOR BRAKE & EPICYCLIC			AS350			
350A32-0100-04	EPICYCLIC			AS350	AS355	EC130	
350A32-0100-10	EPICYCLIC			AS350	AS355	EC130	
350A32-0110-XX	EPICYCLIC			AS350	AS355	EC130	
350A32-0120-XX	EPICYCLIC			AS350	AS355	EC130	
350A32-0300-XX(X)	GEARBOX REDUCTION INCL OIL PUMP & ROTOR BRAKE			AS350			
350A32-0310-XX(X)	GEARBOX REDUCTION INCL OIL PUMP & ROTOR BRAKE			AS350			
350A32-035X-XX	GEARBOX REDUCTION INCL OIL PUMP & ROTOR BRAKE			AS350		EC130	
350A32-0400-XX(X)	PUMP OIL			AS350			
350A32-0500-XX(X)	BRAKE ROTOR			AS350			
350A33-0200-XX	GEARBOX TAIL ROTOR			AS350	AS355		
350A33-0210-XX(X)	GEARBOX TAIL ROTOR			AS350	AS355		

2018 Exchange pool items

350A33-2030-XX	SPIDER TAIL ROTOR INCL BEARING			AS350	AS355		
350A33-2119-XX	HUB TAIL ROTOR			AS350	AS355		
350A33-2167-XX	SPIDER TAIL ROTOR INCL BEARING			AS350	AS355		
350A37-0003-XX	SHAFT ASSEMBLY MAIN ROTOR			AS350			
350A37-0004-XX	SHAFT ASSEMBLY MAIN ROTOR			AS350			
350A37-1004-XX	SWASHPLATE			AS350	AS355		EC130
350A37-1076-XX	POLE MAIN ROTOR SHAFT			AS350	AS355		EC130
350A37-1290-XX	POLE MAIN ROTOR SHAFT			AS350	AS355		EC130
350A75-2050-06	ABSORBER LANDING GEAR SHOCK			AS350	AS355		EC130
350A75-2050-XX	DAMPER LANDING GEAR (EACH)			AS350			
350A75-2080-00	ABSORBER LANDING GEAR SHOCK			AS350	AS355		EC130
350A75-2080-XX	DAMPER LANDING GEAR (EACH)			AS350			
350A76-1020-0052	INDICATOR AIRSPEED			AS350			EC135
350A76-1020-0152	INDICATOR AIRSPEED			AS350			EC135
350A76-1020-0252	INDICATOR AIRSPEED			AS350			EC135
350A76-1035-00	ALTIMETER			AS350			EC135
350A76-1035-02	VERTICAL SPEED INDICATOR			AS350			EC135
350A77-1148-20	SIDESLIP INDICATOR			AS350			EC135
355A37-1030-XX	SWASHPLATE			AS350	AS355		EC130
356H28-01	LIGHT ANTI COLLISION			AS350	AS355		EC130
356H28-02	UNIT POWER SUPPLY			AS350	AS355		EC130
369H2802	POWER SUPPLY			AS350			EC130
371GC01Y02	UNIT POWER SUPPLY			AS350	AS355		EC130
371GC01Y021	BOX MASTER ELECTRICAL			AS350			EC130
374GC01Y	BOX MASTER ELECTRICAL			AS350			EC130
37500-220	ALTIMETER			AS350	AS355		EC135
37500-220 (350A76-1036-06)	ALTIMETER			AS350			EC130
37500-280	ALTIMETER			AS350	AS355		EC135
38210-3641	INDICATOR AIRSPEED			AS350			EC135
38210-480	INDICATOR AIRSPEED			AS350			EC135
38210-490	INDICATOR AIRSPEED			AS350	AS355		EC135

2018 Exchange pool items

38221-01-250	HORIZON GYRO			AS350	AS355		EC135
38222-220	DIRECTIONAL GYRO			AS350			EC135
38222-250	DIRECTIONAL GYRO			AS350			EC135
38399-330 (350A76-1020-0252)	INDICATOR AIRSPEED			AS350		EC130	
38399-480 (350A76-1020-051)	INDICATOR AIRSPEED			AS350		EC130	
38399-480-02	INDICATOR AIRSPEED			AS350			EC135
38399-490	INDICATOR AIRSPEED			AS350			EC135
38399-490/02 (350A76-1020-052)	INDICATOR AIRSPEED			AS350		EC130	
38399-490-02	INDICATOR AIRSPEED			AS350			EC135
39600-584	ALTICODER			AS350	AS355		EC135
399A65-3	VALVE			AS350	AS355	EC130	
418-00165-XXX	COMPUTER AUTO PILOT PA85 T31			AS350	AS355	EC130	
418-00264-XXX	DETECTOR DRIFTING PA85 T31			AS350	AS355	EC130	
418-00404-00X	DETECTOR MOVEMENT PA85 T31			AS350	AS355	EC130	
418-00441-000	MODULE BARO ANEMOMETRIC 85 OR 87			AS350	AS355	EC130	
418-00470-102	COMPUTER AUTO PILOT PA85 T31			AS350	AS355	EC130	
418-00475-XXX	MODULE BARO ANEMOMETRIC 85 OR 87			AS350	AS355	EC130	
418-00478-304	ACTUATOR PITCH CONTROL			AS350	AS355	EC130	
418-00478-554	ACTUATOR AP YAW CONTROL			AS350	AS355	EC130	
418-00487-XXX	COMPUTER TRIM			AS350	AS355	EC130	
418-00500-000	ACTUATOR TRIM			AS350	AS355	EC130	
418-00500-01	UNIT CONTROL COMMAND (CCU) PA85 T39			AS350	AS355	EC130	
418-00529-102	ACTUATOR TRIM			AS350	AS355	EC130	
418-00529-XXX	ACTUATOR TRIM			AS350	AS355	EC130	
418-00579-XXX	COMPUTER AUTO PILOT PA85 T31			AS350	AS355	EC130	
418-00618-XXX	PANEL CONTROL AUTO PILOT PA85			AS350	AS355	EC130	
418-00625-114	ACTUATOR AP ROLL CONTROL			AS350	AS355	EC130	
418-00625-174	ACTUATOR SEMA			AS350	AS355	EC130	
418-00626-003	UNIT FAILURE MONITORING			AS350	AS355	EC130	
418-00626-XXX	PANEL ALARM DETECTOR			AS350	AS355	EC130	
419-00320-XXX	COUPLER FLIGHT DIRECTOR VC85			AS350	AS355	EC130	

2018 Exchange pool items

421721-2	LIGHT RETRACTABLE 450W			AS350	AS355	EC130	
421722-8	LIGHT LANDING RETRACTABLE			AS350	AS355	EC130	
42965 (704A47-612-051)	INDICATOR ROTOR RPM			AS350		EC130	
454-00158-000	GYROSCOPE VERTICAL VG76-1 OR VG76-2			AS350	AS355	EC130	
454-00162-000	GYROSCOPE VERTICAL VG76-1 OR VG76-2			AS350	AS355	EC130	
461-00303-101	COMPASS GYROMAGNETIC CG512			AS350	AS355	EC130	
461-00306-411	PANEL CONTROL CG512			AS350	AS355	EC130	
47750 (704A46-310-000)	MOTOR FAN			AS350		EC130	
500DCF	HORIZON GYRO	DHC6		AS350		EC130	
505-2B	GYRO HORIZON			AS350			EC135
510-1A	GYRO ATTITUDE		DHC8	AS350	AS355	EC130	
510-1B	GYRO ATTITUDE			AS350		EC130	
524-031 series	STARTER GENERATOR			AS350		EC130	
5306-155-00-10	INDICATOR ENGINE OIL PRESSURE			AS350	AS355	EC130	
5306-255-00-10 / -11	INDICATOR OIL TEMPERATURE			AS350		EC130	
5306-265-00-10	INDICATOR ENGINE OIL TEMPERATURE			AS350		EC130	
5306-266-20-10 / -11	INDICATOR ENGINE OIL TEMPERATURE			AS350		EC130	
5306-267-00-10	INDICATOR ENGINE OIL TEMPERATURE			AS350		EC130	
5309-155-00-00 / -10 / -11	INDICATOR FUEL PRESSURE			AS350		EC130	
5352-6	TORQUEMETER TRANSMITTER			AS350			EC135
55103G	VALVE FUEL SHUTT OFF			AS350	AS355	EC130	
5626-519-00	INDICATOR TEMPERATURE			AS350		EC130	
5626-522-0	T4 INDICATOR			AS350			EC135
5626-525-0	INDICATOR T4			AS350	AS355	EC130	
5626-525-00	T4 INDICATOR			AS350		EC130	
5626-555-00-11	T4 INDICATOR			AS350	AS355	EC130	
5633-707-80-00 / -11 / -12	INDICATOR DELTA			AS350		EC130	
5633-707-80-12	NG INDICATOR			AS350	AS355	EC130	EC135
5637-560-00-10	T4 INDICATOR			AS350		EC130	EC135
5934-1	ALTIMETER			AS350		EC130	
61476-402-1	TACHOMETER			AS350		EC130	

2018 Exchange pool items

64130-102-1	ALTIMETER			AS350	AS355		EC135
64251-903-2	TRANSMITTER TORQUE			AS350	AS355	EC130	
64279-004-1	OIL PRESSURE TRANSMITTER			AS350			EC135
64304-030-1	SWITCH FUEL DIFFERENTIAL PRESSURE			AS350	AS355	EC130	
64350-068-4	NG INDICATOR			AS350			EC135
64530-068-03 / -04	METER TACHO			AS350		EC130	
64538-068-1	TURBINE TACHOMETER INDICATOR			AS350			EC135
64751-100-1	TRANSMITTER FUEL LEVEL			AS350	AS355	EC130	
64757-101-2	TRANSMITTER FUEL GAUGE			AS350	AS355	EC130	
64818-010-1	OIL PRESS IND			AS350		EC130	
64818-013-1	OIL PRESSURE INDICATOR (BARS)			AS350			EC135
64818-015-1	OIL TEMPERATURE INDICATOR			AS350			EC135
6503A-1032	TACHOMETER INDICATOR			AS350			EC135
6503A-1058	TACHOMETER INDICATOR			AS350			EC135
684-4143-100	INVERTER STATIC			AS350	AS355	EC130	
7030 C.27	VERTICAL SPEED INDICATOR			AS350			EC135
704A34-310-006	PUMP HYDRAULIC			AS350	AS355	EC130	
704A46-814-049	DIMMER LIGHT			AS350		EC130	
704A47-723-006	PANEL MASTER CAUTION			AS350		EC130	
704A4A7-650-116	FUEL GAUGE INDICATOR			AS350			EC135
744-098-1	INDICATOR FUEL FLOW			AS350			EC135
7813-175-00-13	INDICATOR TRIPLE ROTOR RPM			AS350	AS355	EC130	
857A16-41	VALVE			AS350	AS355	EC130	
9509-2	MOTOR			AS350		EC130	
9599-607-12183	INDICATOR RADIO ALTIMETER			AS350	AS355		EC135
9599-607-12185	INDICATOR RADIO ALTIMETER			AS350	AS355		EC135
986C12-5	VALVE NON RETURN			AS350	AS355	EC130	
AC67032	SERVO TAIL ROTOR			AS350			
AC67244	SERVO TAIL ROTOR			AS350			
AC67246	SERVO TAIL ROTOR			AS350			
B18-945-22-28-2A	CHRONOGRAPH			AS350	AS355	EC130	

2018 Exchange pool items

BFS150 --> BFS150-1	VALVE, FILTER BLOCK			AS350	AS355	EC130	
BFS150A-1	VALVE, FILTER BLOCK			AS350	AS355	EC130	
BFS155	VALVE, FILTER BLOCK			AS350	AS355	EC130	
BFS155 --> BFS155-1	VALVE, FILTER BLOCK			AS350	AS355	EC130	
BFS155-1	VALVE, FILTER BLOCK			AS350	AS355	EC130	
BFS156-1	VALVE, FILTER BLOCK			AS350	AS355	EC130	
BHC1080	UNIT, HYDRAULIC CONTROL			AS350	AS355	EC130	
C11BC0081	FUEL PUMP			AS350	AS355	EC130	
G6250 (series)	POWER SUPPLY ANTI COLLISION			AS350		EC130	
GC10257-(series)	POWER SUPPLY ANTI COLLISION			AS350		EC130	
GV76-2	VERTICAL GYRO			AS350	AS355		EC135
H140BHM2	HORIZON GYRO			AS350	AS355		EC135
H140JAM1	HORIZON GYRO			AS350	AS355		EC135
HE402F (9580115210)	POWER SUPPLY ANTI COLLISION			AS350		EC130	
HE900 (9550164470)	POWER SUPPLY ANTI COLLISION			AS350		EC130	
HE901 (9550176020)	POWER SUPPLY ANTI COLLISION			AS350		EC130	
HE932 (9550177760)	POWER SUPPLY ANTI COLLISION			AS350		EC130	
IND 21	INDICATOR RADIO ALTIMETER			AS350			EC135
KA 51A	SLAVING ACCESSORY			AS350			EC135
KA 51B	SLAVING ACCESSORY			AS350			EC135
KCA0113W	COMPASS STANDBY			AS350	AS355	EC130	
KG 102A	DIRECTIONAL GYRO	DHC6		AS350			EC135
KI 227	ADF INDICATOR			AS350			EC135
KI 229	R.M.I.			AS350			EC135
KI 525A	PICTORIAL NAVIGATION INDICATOR	DHC6		AS350			EC135
KMT 112	FLUX VALVE	DHC6		AS350			EC135
ME9611	MOTOR WINDSHIELD WIPER			AS350	AS355	EC130	
MS5750V01	POWER SUPPLY ANTI COLLISION			AS350		EC130	
MS5750-V01	MOTOR ELECTRICAL			AS350	AS355	EC130	
P94B12-209	PUMP FUEL			AS350	AS355	EC130	
P94B12-213	PUMP FUEL			AS350	AS355	EC130	
P94C16-602	PUMP FUEL			AS350	AS355	EC130	

2018 Exchange pool items

RCA 15BK-2	DIRECTIONAL GYRO			AS350			EC135
RCA 26BK-8	HORIZON GYRO			AS350			EC135
RCA15BK-2	GYRO DIRECTIONAL			AS350		EC130	
RCA15BKB	GYRO DIRECTIONAL			AS350		EC130	
RCA26BK-8	GYRO ATTITUDE			AS350		EC130	
RH21-13	COOLER OIL ENGINE			AS350	AS355	EC130	
RH21-15	COOLER OIL ENGINE			AS350	AS355	EC130	
RH25-16	COOLER OIL ENGINE			AS350	AS355	EC130	
RPR3	CONTROLER, PRESSURE			AS350	AS355	EC130	
SC5071	SERVO, TAIL ROTOR			AS350	AS355	EC130	
SC5071-1	SERVO, TAIL ROTOR			AS350	AS355	EC130	
SC5071-1 --> SC5072	SERVO, TAIL ROTOR			AS350	AS355	EC130	
SC5072	SERVO, TAIL ROTOR			AS350	AS355	EC130	
SC5081 --> SC5083	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5081 --> SC5083-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5081-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5081-1 --> SC5083	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5081-1 --> SC5083-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5082	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5082 --> SC5084	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5082 --> SC5084-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5082-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5082-1 --> SC5084	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5082-1 --> SC5084-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5083	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5083 --> SC5083-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5083-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5084	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5084 --> SC5084-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC5084-1	SERVO, MAIN ROTOR			AS350	AS355	EC130	
SC8042	SERVO, MAIN ROTOR			AS350	AS355	EC130	

2018 Exchange pool items

SC8043	SERVO, MAIN ROTOR				AS350	AS355		EC130	
SEDL-OC329A (350A-82-1267-01)	INDICATOR DUAL TACHO				AS350			EC130	
SEL-OC19BF (350A-82-1283-02)	INDICATOR TEMPERATURE				AS350			EC130	
SEL-OC19EG	T4 INDICATOR			EMB120	AS350				EC135
SP03301	ALTIMETER				AS350				EC135
TSG420-103	INVERTER STATIC				AS350	AS355		EC130	